



CHEMICAL SPECIALTIES LTD

TURBO

BUILDER'S BOG

Directions to mix Turbo Builder's Bog with Red Hardener.

Example for 100g putty to gel after 7 minutes at 22°C.

1. Use a thin screwdriver to separate lid from can.
Use the plastic overcap as a mixing plate or any other suitable flat non-absorbent surface.



2. Weigh out 100g of Turbo Builder's Bog. (125 ml.)

or

- 2a. Measure out 1^{1/4} cupfuls (300 ml.)



3. Weigh out 2.5g red hardener.

or

- 3a. 1 level teaspoonful (5 ml.)



4. Combine Turbo Builder's Bog and Red Hardener. Mix well to a uniform colour (no white and red streaks visible).



5. Ready for use!



6. Gelled after 7 minutes at 22°C.



7. Cured, ready for sanding and painting after 45 minutes.

The product will gel ("set") to a cheese-like consistency first. At this stage cut, chisel, grate or pare it. Then wait about 30 - 60 minutes for full cure. Then sand & paint it.

Amount	Product	Amount	Product	Gel time (approx.)	Weather °C
100g	Turbo Builder's Bog	2.5g	Red Hardener	7 minutes	22°C
100g	Turbo Builder's Bog	5g	Red Hardener	8 minutes	15°C
100g	Turbo Builder's Bog	1.5g	Red Hardener	5 minutes	30°C

Warmer climates: less hardener will result in the same gel time.

Longer work time needed before gelling starts? Use less hardener.

Note:

Timber must be clean, dry, non painted & roughened and rot-free.

